

Fundamentals of Engineering High-Performance Actuator Systems

$$x = x_0 + v_0 t + \frac{1}{2} a_0 t^2 + \frac{1}{6} j t^3$$

Kenneth W. Hummel